

# Projectors: Changing the Screen Resolution



A common screen resolution for a computer being used with a projector is 1024 x 768. For normal viewing, a laptop's screen resolution may be set much higher (1280 x 800) which is fine, but if you need to properly project what is displayed on the laptop, you will need to make an adjustment in the Display Properties.

To access the Display Properties, do the following:

1. **Right-click** in a blank area of the desktop and select **PROPERTIES**.



2. Once the window opens, select the **SETTINGS** tab.
3. Under *Screen Resolution*, slide the adjuster to the left until it shows **1024x768**.
4. Click **OK**. The screen will flicker, but once it returns, your desktop will display properly through the projector onto the screen.

