

Sleep Mode for Epson Projectors

When the Sleep Mode is enabled, the projector turns off the lamp if it has not received any signals for a period of time defined in the Sleep Mode Time setting.


To access the Operation features of the projector, first turn the projector on with the remote control. Once you are able to see your pc's desktop, press the Menu button on the remote.



To navigate in a direction, you will use the arrow buttons on the remote labeled with the numbers 2, 4, 6 and 8. To select an option, press the Enter button labeled with the number 5.

To access the projector's Sleep Mode features, do the following:

1. Press the MENU button on the remote.
2. Navigate to the EXTENDED menu option and press the RIGHT button.
3. Go to OPERATION and press ENTER on the remote.
4. Navigate to SLEEP MODE and press ENTER.
5. Select ON and press ENTER.



Once the Sleep Mode is On, the default for the Sleep Mode Time setting should be 10 minutes. If not, do the following:

1. Go to the SLEEP MODE TIME setting and press ENTER.
2. Using the LEFT/RIGHT arrows, adjust the time to 10 minutes.
3. Press ENTER.
4. Press the MENU button to exit the projector setup.

